




## T46

### PLACE A CALL

- Pick up the handset, or press the **Headset** or the **Speakerphone** button
- Dial number, and then press the **Send** soft key

### ANSWER A CALL

- Pick up the handset. 
- Press the **Headset** button 
- Press the **Speakerphone** button 
- Press the **Answer** soft key

### END CALLS

You can only end active calls. To end an On Hold call, you must resume the call first.

#### To End an Active Call:

-  Replace the handset in the cradle.

Press the **End Call** soft key

And if using a headset or the speakerphone:

-  Press the **Headset** button

-  Press the **Speakerphone** button

### HOLD & RESUME



On hold call displays only on the device used to place the call on hold.

- While on an active call press the **Hold** button located on the right side of phone.
- Press the same **Hold** button to **resume** the call before picking up the handset.
- Press the **Hold** soft key
- Call can be resumed by using the **Resume** soft key.



### TRANSFER CALLS

Transfer calls to any extension

#### Consulted/Warm Transfer

- Press  or tap the **Transfer** soft key
- Enter or select the extension or phone number and press **Send**, **OK** or the **#** button to dial and wait for an answer.
- Speak to the recipient and press  tap the **Transfer** soft key again to send the call when ready.

#### Blind/Cold Transfer

- Press  or tap the **Transfer** soft key
- Dial or select the ext/phone number
- Press  or tap the **Transfer** soft key again.

### CONFERENCE CALL

Add a 3<sup>rd</sup> caller to an active call.

#### To Conference:

1. Press the **Conference** soft key to place the current call on hold.
2. When you hear a dial tone, dial the number or extension of the person you wish to add to make a 3-way call.
3. When they answer, press the **Conference** soft key again.

### GET VOICEMAIL MESSAGES

#### From Your Phone:

1. Press the **Messages** button.
2. Enter your 4 digit PIN when prompted.
3. Select the appropriate option from the voicemail menu prompts.

#### From Anywhere:

1. Call the extension's 10-digit number
2. Press the **\*** key when the voicemail announcement begins to access the Voicemail menu prompts.

## Yealink T46 Phone Interface



Examples provide typical steps for usage of the standard configuration setup. Contact Customer Service/Support for assistance with customized configurations.






## T48

### PLACE A CALL

- Pick up the handset, or press the **Headset** or the **Speakerphone** button
- Dial number, and then press the **Send** soft key on the screen

### ANSWER A CALL

- Pick up the handset. 
- Press the **Headset** button 
- Press the **Speakerphone** button 
- Press the **Answer** soft key on screen

### END CALLS

*You can only end active calls. To end an On Hold call, you must resume the call first.*

#### To End an Active Call:

 Replace the handset in the cradle.

Press the **End Call** soft key

And if using a headset or the speakerphone:

 Press the **Headset** button

 Press the **Speakerphone** button

### HOLD & RESUME



*On hold call displays only on the device used to place the call on hold.*

- While on an active call press the **Hold** button located on the right side of phone.
- Press the same **Hold** button to **resume** the call before picking up the handset.
- Or, tap the **Hold** soft key on screen
- Call can be resumed by tapping the **Resume** soft key.



### TRANSFER CALLS

*Transfer calls to any extension*

#### Consulted/Warm Transfer

- Press  or tap the **Transfer** soft key
- Enter or select the extension or phone number and press **Send**, **OK** or the **#** button to dial and wait for an answer.
- Speak to the recipient and press  or tap the **Transfer** soft key again to send the call when ready.

#### Blind/Cold Transfer

- Press  or tap the **Transfer** soft key
- Dial or select the ext/phone number
- Press  or tap the **Transfer** soft key again

### CONFERENCE CALL

*Add a  a caller to an active call.*

#### To Conference:

1. Press the **Conference** soft key to place the current call on hold.
2. When you hear a dial tone, dial the number or extension of the person you wish to add to make a 3-way call.
3. When they answer, press the **Conference** soft key again.

### GET VOICEMAIL MESSAGES

#### From Your Phone:

1. Press the **Messages** button.
2. Enter your 4 digit PIN when prompted.
3. Select the appropriate option from the voicemail menu prompts.

#### From Anywhere:

1. Call the extension's 10-digit number
2. Press the **\*** key when the voicemail announcement begins to access the Voicemail menu prompts.

## Yealink T48 Phone Interface



Examples provide typical steps for usage of the standard configuration setup. Contact Customer Service/Support for assistance with customized configurations.

